



**STEP NO.1:**  
**LAY ALL PANELS & CONNECTORS IN LINE AS PHOTO SHOWING,**  
**AND ASSEMBLED!!!**



**STEP NO.2:**  
**BY TOP&BOTTOM CONNECTOR INSERT ASSEMBLED,**  
**AS PHOTOS SHOWING !!!**





**STEP NO.3:**

**ONE BY ONE STEP, FINISH THE TOP ROOF FRAME ASSEMBLED.**



**STEP NO.4:**

**WATERPROOF COVER ASSEMBLED, USING ELASTIC STRING FIXED.  
SO, IT IS COMPLETED!!!**